



TROCEN[®]

Motion Control is Trocen

AWC708S Motion Control User Manual

Laser Motion Control



2018.08

www.sztrocen.com

Copyright © 2016 Trocen Automation Tech. Co. Ltd. All Rights Reserved

Copyright

Shenzhen Trocen Automation Tech. Co. Ltd. (Hereinafter referred as Trocen) reserves the right to modify the products and product specifications in this manual without prior notice.

Trocen is not liable for any loss or liability arising directly, indirectly, specifically, incidental or consequential due to the use of this manual or this product.

The company has the patent, copyright and other intellectual property rights of the product and its software. Without authorization, it shall not directly or indirectly reproduce, manufacture, process, use this product and its related parts.



Users have the responsibility to pay attention to the design error and establish protection mechanisms. Trocen doesn't accept any responsibility or liability for any damage or loss resulting from improper operation.

Contact Us

[Shenzhen Trocen Automation Tech. Co. Ltd.](#)

First Floor, Building 4, Zhiheng Industrial Park, Nantou Pass Second Road,
Nanshan District, Shenzhen City, Guangdong Province, China

Tel: +86-0755-27958262

Fax: +86-0755-27447913-608

Email: qiancheng@sztrocen.com

Website: www.sztrocen.com

Introduction

Thanks for Choosing Trocen Motion Control

In order to feedback customers, we will help you to complete the production of the equipment with first-class quality motion controller, perfect after-sales service and efficient technical support.

More Information about Trocen Products

You could get more information about the company and products on our website www.sztrocen.com , including company profile, product introduction, technical support and the latest release products, etc.

You could call +86 (0755) 27958262 for more information.

Technical Support & After-Sales Service

You could contact technical support and after-sales service by the following ways:

Email: qiancheng@sztrocen.com

Tel: +86-0755-27958262

Fax: +86-0755-27447913-608

Address: First Floor, Building 4, Zhiheng Industrial Park, Nantou Pass
Second Road, Nanshan District, Shenzhen City, Guangdong
Province, China

Code: 518100

User Manual

Users will know the basic composition, installation and how to use AWC708S by reading this instruction.

For Who

This manual is applicable to engineers who have a certain understanding of laser mechanical automation and electrical circuits.

Main Content

The composition, installation and use of AWC708S are introduced in detail

Relevant Document

《LaserCAD User Manual》

Content

1. Product Introduction	8
1.1 System Introduction	8
1.2 Terms and Explanation	9
1.3 Unpack	9
1.4 Panel Preview	11
1.5 Buttons.....	12
1.5.1 Function Keys	12
1.5.2 Direction Keys.....	15
1.6 Wiring Board	16
1.6.1 Wiring Board Appearance.....	17
1.6.2 Port Instruction.....	18
2. LaserCAD Installation	28
3. Simplified Installation.....	29
3.1 Hardware Connection.....	29
3.2 Input Test	30
3.3 Set the Origin Point of Machine.....	31
3.4 Key Direction	32
3.5 Distance Per Pulse	32
3.6 Hard Limit and Range	33
4. Main Interface Preview	35
5. Main Page Function Introduction	37
5.1 File	37

5.1.1 Document Params Settings	37
5.1.2 Layer Params Settings	39
5.2 Count.....	41
5.3 Working Property	42
6. System Menu	44
6.1 U Disk Files	44
6.1.1 Work Files	46
6.1.2 Config Files	47
6.1.3 Upgrade Files	48
6.1.4 Save Current Config to U Disk	49
6.2 Origin Manage.....	49
6.3 Jog Control	51
6.4 Cut Box.....	52
6.5 Axes Control	53
6.6 Motion Parameters Settings	54
6.7 Common Parameters Settings	57
6.7.1 Work Mode.....	57
6.7.2 Common Parameters	62
6.7.3 Axis Speed Parameters	64
6.7.4 Rotate Engraving & Cutting.....	66
6.8 Network Settings	70
6.9 Language	72
6.10 System Version	72

7. Manufacture Params Settings	75
7.1 Axis Parameters	75
7.2 Laser Parameters	79
7.3 I/O Parameters	81
7.4 Auto Reset Settings	82
7.5 HardLimit Settings	83
7.6 Function Config	84
8. FAQ	85
Appendix 1: Wiring Diagram of Servo Driver	86

1. Product Introduction

1.1 System Introduction

AWC708S is a universal motion controller for laser cutting, laser engraving and other fields developed by Shenzhen Trocen Automation Tech co., LTD. This controller featured with single-head cutting that can meet the requirement of laser in low/medium power, is designated for laser cutting/engraving machine, used for toys and gifts, clothing, acrylic or packaging fields. This system is used by LaserCAD software and motion controller, which greatly improves the production efficiency and reduces the production cost.

Features of LaserCAD

- User-friendly and versatile
- Support CorelDraw, Auto CAD and other professional drawing software.
- Support the file format: AI, PLT, DXF, SVG, PDF, NC, DST, DSB, UD5, BMP, GIF, JPG, JPEG, PNG.
- Simple graphics drawing function.
- Support Z AutoFocus function.

Features of Wiring Board

- High DSP, quick calculating and optimal algorithm.
- 4.3'' color TFT LCD display with concise operation interface.

- Optical coupler, anti-electromagnetic interface and system stability.
- Faster reading files under USB, U Disk and network.

1.2 Terms and Explanation






Table1-2-1 Terms and Explanation

Term	Explanation
LaserCAD Software	LaserCAD is a complementary software with auto typesetting for laser motion control.
TFT LCD Panel LCD Panel Control Panel Panel	4.3" color TFT LCD control panel. The panel is used for specific display and control operations and it is an important part of the system.
Wiring board (Baseboard)	The baseboard is the control board of the integrated signal (input and output) control and the motor drive connection.
Hardware	Includes: mainboard, wiring board, wire and so on.

1.3 Unpack

After receiving the product, please confirm whether the product and accessories are complete. If there is a lack of accessories, please contact the after-sales service of Trocen company.

Table1-3-1 Wire Introduction

Name	Appearance	Introduction
Panel and mainboard		The panel (mainboard) of AWC708S.
Wiring Board		The wiring board of AWC708S.
USB Cable (3m)		Connect computer and panel by USB.
CN Cable (1.6m)		There is one CN cable to connect the CN port of main board and wiring board.
8 PIN (1m)		Patch cord with USB and network port.

1.4 Panel Preview

There are LCD display, soft keys and U disk slot on panel.

Figure1-4-1 Panel Preview





Figure1-4-2 Size of Main Board









1.5 Buttons







According to the different use of keys, all keys are roughly divided into two categories: function keys and direction keys.

1.5.1 Function Keys

Function key is designed to directly realize a specific operation function.


Table1-5-1 Function Keys Instruction

Name	Icon	Instruction
Reset		No matter what the state of the machine is in, pressing this button will make it enter the resetting state.
File		Browse the files stored in the control board.
Box		Frames the working area from the origin point of the current file.
Menu		Show the main menu.
Shift		Combine function key.
Laser		Test usage. Press the key, the laser tube will give out light. It's used to adjust optical path.

Origin		Setting machine's starting point of the current file.
Stop		Once pressed, the machine will stop its current function and move back to its origin.
Start/Pause		Pause the machine and keep it stay at location. Press again to resume.
Esc		Exit edit mode (Exit cursor). Return to previous menu.
Enter		Enter edit mode (Start cursor). Confirm the current operation.
Hand		Switch the moving speed of laser head manually (fast-slow).


On the main page, press **【File】** and users can see the memory files stored in the mainboard.

Figure1-5-1 File Interface




Move cursor to the file you need, press **【Enter】** , you could set the file parameters.

Figure1-5-2 File Parameters Setting Page



- Move cursor to **【Select】** , press **【Enter】** and set current file as work file.
- Move cursor to **【Data Check】** , press **【Enter】** . If the graphics is the same as that in PC, the system will prompt “File Data OK!”, then the graphics will be allowed to process. If not, the machine won’t process this graphics.

Figure 1-5-3 File Format Test



You could set other parameters as your need.

1.5.2 Direction Keys

- **【↑】【↓】【←】【→】**

They are used to move the X/Y axis and cursor, also used to modify options in the current view.

- **【z ↑】【z ↓】**

Used to modify parameters when the cursor is colored backwards.

Move cursor when the direction keys **【↑】【↓】【←】【→】** are occupied.

1.6 Wiring Board

The panel and other parts of machine are connected by wiring board. The components as below:

- Connect motor driver
- Detection of motion axis limit signal
- Input signal detection
- Output IO control signal and corresponding power supply

1.6.1 Wiring Board Appearance

Figure1-6-1 Wiring Board Appearance





Figure1-6-2 Wiring Board Ports Introduce



1.6.2 Port Instruction

1.6.2.1 Power Supply Port

The power supply ports provide power to wiring board and panel. Please pay more attention to polarity when connect them. Don't make the polarity reverse.

Table1-6-1 Instruction of Wiring Board Power Supply Port

Pin	Name	Introduction
1	GND	Negative pole.
2	+24V	24V positive polarity.

1.6.2.2 Port of Panel and Wiring Board

Connect panel and wiring board with CN cable.

Table1-6-2 Port of Panel and Wiring Board

Name	Introduction
CN	Connect panel and wiring board by CN port.

1.6.2.3 Signal Input


There are two groups of signal input ports.

Table1-6-3 Wiring Board Signal Input Port Instruction

	PIN	Name	Instruction
IN	1	GND	Power ground
	2	IN1	Door open protection signal (This function needs to be turned on in the panel to be effective).
	3	IN2	Foot switch (This function needs to be turned on in the panel to be effective).
	4	IN3	Reserved
	5	IN4	Reserved
	6	DC24V	Output DC voltage (24V)

Wiring diagram of signal input:

Figure1-6-3 Wiring Diagram for Signal Input



1.6.2.4 Signal Output

There is one group of output ports to supply power and control signals. If you choose OUT2 (Blow when laser is power on), you must set the parameters of 【Blow Open Delay】 or 【Blow Close Delay】 on the **Common Parameter** interface, with the minimum value of 0.01.


Table1-6-4 Output Port Instruction

	PIN	Name	Instruction
OUT	1	GND	Power ground (OUT).

	2	OUT1	Blowing signal (blow all the working time): OUT1 Blowing when output is high logic level. OUT1 Do not blow when output is low logic level.
	3	OUT2	Blowing signal (blow when laser is powering on): OUT2 Blowing when output is high logic level. OUT2 Do not blow when output is low logic level.
	4	OUT3	Reserved
	5	OUT4	Reserved

Output signals control laser blowing generally. The wiring diagram is shown below (blow all the working time).

Figure1-6-4 Blowing Control Diagram



1.6.2.5 Laser Power Supply Port

The wiring board provides 1 group of laser output control ports.

Table1-6-5 Laser Controller Output Instruction

	PIN	Name	Instruction
Laser	1	GND	Power ground.
	2	TTL	Laser switch signal.
	3	PWM	Digital signal. The output voltage is 0~5V, and it will change according to the power.
	4	WP	Water Protection.
	5	DC5V	Output DC voltage (5V).

Different lasers have different connection modes. Take ordinary glass tube laser as example. The optical signal of ordinary glass tube laser is 5V, and set low level for light emitting. The power signal PWM of main board is connected to the IN pin of laser power source and TTL to the L pin of laser power source. All signals have uniqueness, which is connected to this group of signals, other pins do not need to be connected. You could connect the water tank by the WP pin (water protection) of the main board or the P pin (water protection) of laser power supply, and please pay attention that you could only choose one of them. For the RF tube laser power supply, only connect the PWM of the main board to the IN pin,

GND to G pin, and no need to connect TTL pin.

Figure1-6-5 Ordinary Glass Tube Laser Diagram





Figure1-6-6 Pins of Laser Power Source



If the laser light control signal is low level, connect the L pin of laser power, and if the laser light control signal is high level, connect the H pin of laser

power.

1.6.2.6 Motor Drive Control Port

The wiring board can provide up to 3 motor driver connections, and users can choose step driver or servo driver according to the need. The servo driver has higher control accuracy than step driver. Users can choose the appropriate driving mode according to the usage scenario, cutting precision requirements and cost factors. We take the step driver as an example. [Various types of servo driver wiring diagram, please refer to Appendix 1 of this article.](#)


Table1-6-6 Motor Driver Connection Instruction

	PIN	Name	Instruction
X	1	DIR	Direction signal
	2	PUL	Pulse signal
	3	DC5V	Output DC voltage (5V)
Y	1	DIR	Direction signal
	2	PUL	Pulse signal
	3	DC5V	Output DC voltage (5V)
Z	1	DIR	Direction signal
	2	PUL	Pulse signal

	3	DC5V	Output DC voltage (5V)
--	---	------	------------------------

The diagram below shows the connection of step driver.

Figure1-6-7 Diagram of Driver Connection




1.6.2.7 Limit Signal

The wiring board provides 3-way sensor limit signal access. This system supports working range limitation, so users do not need to install hard limit sensor, just set the **【Range】** parameter on the **Axis Parameters** page.

Table1-6-7 X/Y Limit Signal Input

	PIN	Name	Instruction
Limit	1	GND	Power ground.
	2	ELX-	The origin limit of the X axis. The input signal of origin limit sensor, when the X axis moves to the minimum coordinate position (zero position).
	3	ELY-	The origin limit of the Y axis. The input signal of origin limit sensor, when the Y axis moves to the minimum coordinate position (zero position).
	4	ELZ-	The origin limit of the Z axis. The input signal of origin limit sensor, when the Z axis moves to the minimum coordinate position (zero position).
	5	ELZ+	The hard limit of Z axis. The input signal of hard limit sensor, when Z axis moves to the maximum coordinate position.
	6	DC24V	Output DC voltage (24V).

Figure1-6-8 Diagram of Limit Signal



2. LaserCAD Installation


You can go through 《LaserCAD User Manual》 for more details about installation and how-to-use LaserCAD.

3. Simplified Installation

The content of this chapter is mainly about the hardware initial installation of the product and the setting of basic software parameters. Please refer to the following chapters of this article for the detail settings and descriptions of other parameters.

3.1 Hardware Connection

Figure3-1-1 Integral Wiring Diagram



- Figure 3-1-1 shows the diagram of ordinary glass tube laser.
- Connect the blow control ports to corresponding electromagnetic valves to control blow.

- Connect the axis limit ports to corresponding axis limiters.
- Please [refer to the Chapter 1.6.2.6](#) to know more detail about X/Y/Z motor driver connection.

3.2 Input Test

On the main page, press **【Stop】** and press **【Menu】** two times at the same time, you will see the **Input Test** interface.

Figure3-2-1 Input Test Interface

输入口测试		2018.8.27 10:35	
X-限位	1	W+限位	0
X+限位	1	IN1	1
Y-限位	1	IN2	1
Y+限位	1	IN3	1
Z-限位	1	IN4	1
Z+限位	1	水保护1	1
V-限位	1	水保护2	1
V+限位	0	水保护3	1
W-限位	1	水保护4	1

According to different types of sensors, you could choose metal products or other shielding objects to close to the sensors in order to detect whether the signals changes, so as to confirm whether the wiring is accurate and effective.

3.3 Set the Origin Point of Machine

Connect machine and wiring board as Figure3-1-1. Power on and observe the motion of axis. If the axis moves random, please press **【Stop】** at once. Check your installation and wiring of limiters, if no mistake, then modify the direction of origin point and reset machine.

On the main page, press **【Stop】** and **【Shift】** at the same time to enter the **Manufacture Parameters Settings** page. Users could set axis parameters (Datum direction/Key direction/Limit Polarity and so on) on the **Axis Parameters** page.

Figure3-3-1 Axis Parameters Interface

X Axis Parameters		2019.1.18 10:35
➡	Distance Per Pulse (um) ...	06.500000
	Valid Pulse Edge	Failling Edge
	Datum Direction	Negative
	Key Direction	Negative
	Limit Polarity	Negative
	Range (mm)	00500
	Start Speed (mm/s)	15.0
	Max Acc (mm/s ²)	10000
	Max Speed (mm/s)	0500.0
	Zero Offset (mm)	003.0

Reset the machine, and observe the motion direction of axis again. Before start, please make sure to enable the axis auto reset function. [Detail settings refer to Chapter 7.4.](#)

3.4 Key Direction

On the main page, press 【↑】【↓】【←】【→】【Z↑】【Z↓】 to move X/Y/Z axis, and check whether the motion direction is the same as key direction. If not, please modify the 【Key Direction】 on the axis parameters page.

3.5 Distance Per Pulse

Distance per pulse refers to the actual distance of motion axis for each pulse instruction sent by the controller.

Distance per pulse of X/Y/Z axis (take X axis as example)

1. Open the 【XY AutoReset】 function, and reset machine, then mark the current position of laser head with A.
2. On the main page, press 【Menu】 and enter the *Jog Control* page. Set the 【Jog Distance】 to 200mm as example. Then press 【Enter】 to save your modification. If you did not set the 【Range】 on *Axis Parameters* page, please do not set the 【Jog Distance】 value too large.
3. On the *Jog Control* page, move cursor to 【X/Y Jog】 , then press direction key (【←】 / 【→】) one time to make the laser head move a jog distance on the X direction. Mark the current position of laser head with B.
4. Measure the distance between A and B, then input the value into 【Actual Length】 .

5. On the main page, press **【Stop】** + **【Shift】** at the same time to open the **Manufacture Params Settings** page. Then move cursor to **【Axis Parameters】** option and press **【Enter】** . Then open the **X Axis Parameters** page and move cursor to **【Distance Per Pulse】** , press **【Enter】**. Input 200mm into **【Expected Length】** and input the distance between A and B into **【Actual Length】** . Then press **【Enter】** , the distance per pulse of X axis will be calculated.
6. The calculation method of Y axis is the same as X axis.
7. When Z axis works as lifting shaft or platform lifting shaft, the calculation method is the same as X axis.



When the pulse distance value of any axis is close to or less than 1, the pulse distance can't be adjusted and is always 1. Users need to adjust pulse of motor driver first, then measure the distance per pulse again. The recommended pulse distance value is 5 or more.

3.6 Hard Limit and Range


On the main page, press **【Stop】** + **【Shift】** at the same time to open the **Manufacture Params Settings** page. Then move cursor to **【HardLimit Settings】** and press **【Enter】** , users can enable or disable the hard limit parameters. AWC708S supports range function, so users don't need to install hard limit sensors, just setting **【Range】** parameters on the relevant axis parameters page will be enough.

Set the distance per pulse of X/Y/Z axis according to the content of the

Chapter 3.5. Then move motion axis to the maximum distance towards positive direction. You can set the coordinate value on the panel as **【Range】** .

4. Main Interface Preview

Figure4-1 Main Interface



Speed/Power/Time/Status:

1. Work: Working parameters;
2. Idle: Laser power.

Table4-1 Main Interface Introduce

Name	Instruction
Top Bar	Display the type of control card, local date and time.
File	Display the file name currently being processed.
Count	Current counts Cumulative counts.
Speed (mm/s)	Cutting speed of laser head.

Max Power Min Power	Displays the Max & Min power of laser head. Max power means working power. Min power means turning power. During cutting process, if the cutting lines is uneven (different cutting depth), the maximum and minimum power of laser head should be adjusted to ensure the best cutting effect. If the maximum and minimum power is set too high, the cutting material may be damaged. If set too low, may cause incomplete cutting. Users shall set appropriate maximum and minimum power values according to different cutting materials.
Time	Displays the total working time.
Status	Displays the machine state. Includes working state, idle state, pause state. There will be a percentage to show the working process of the current file under working state.
X/Y/Z	Displays the X/Y/Z coordinate.

5. Main Page Function Introduction

5.1 File

5.1.1 Document Params Settings

On the main page, press **【Enter】** to make the file name highlighted as shown below. Then press **【Enter】** to open ***Document Params Settings*** interface.

Figure5-1-1 Select File Name





Figure5-1-2 Document Params Settings



Move the cursor to **【Document Property Settings】** , press **【Enter】** . Press **【↑】【↓】【←】【→】** to move cursor, press **【Z↑】【Z↓】** to modify parameters, and press **【Enter】** to save settings.

Figure5-1-3 Set Document Property




Table5-1-1 Set Document Property Instruction

Name	Instruction
Repeat Count	Machine repeat working times.
Repeat Delay (s)	The interval between the initial file being finished and the next one of the same.
X Count	The number of graphics s processed by machine in the X direction.
Y Count	The number of graphics s processed by machine in the Y direction.
X Size (mm)	The size of graphics in X direction.
Y Size (mm)	The size of graphics in Y direction.

5.1.2 Layer Params Settings

On the **Document Params Settings** page, move cursor to **【Layer Params Settings】** and press **【Enter】**. On the **Layer Params Settings** page, press **【↑】【↓】【←】【→】** to move cursor, press **【Z↑】【Z↓】** to modify parameters, press **【Enter】** to save settings.

During cutting current layer, if the cutting lines are uneven (different cutting depth), the maximum and minimum power of the laser head shall be adjusted to ensure the best cutting effect. If the maximum and minimum power is set too high, the cutting material may be damaged. If

set too low, may cause incomplete cutting. Users could set appropriate maximum and minimum power values according to different cutting materials.

Figure5-1-4 Layer Params Setting

Layer Params Settings

➔	Work Mode	Cut
	Speed (mm/s)	0300.0
	MaxPower (%)	50.0
	MinPower (%)	40.0

Table5-1-2 Layer Params Setting Instruction

Name	Instruction
Work Mode	The mode of processing graphics.
Speed (mm/s)	The speed of processing graphics.
Max Power (%)	The max power of laser head (working power).
Min Power (%)	The min power of laser head (turning power).

5.2 Count

On the main page, press **【Enter】** , then move cursor to **【Count】** . Press **【Enter】** . Move cursor to **【To Clear Current count】** and press **【Enter】** to clear the current counts. Move cursor to **【To Clear Cumulative Counts】** and press **【Enter】** , the cumulative counts will change to zero.

Figure5-2-1 Clear Total Count






Figure5-2-2 Clear Total Count



5.3 Working Property

On the main page, press **【Enter】** to make the cursor highlighted and move cursor to **【Speed】** . Press **【Enter】** to open ***Set Laser Power While Idle*** page.

Figure5-3-1 Select Speed Option



Press 【↑】【↓】【←】【→】 to move cursor, press 【Z↑】【Z↓】 to modify parameters, and press 【Enter】 to save settings.

Figure 5-3-2 Idle Laser Power Setting Page

Set Laser Power while Idle
2019.1.18 10:35

➡

Key Move Speed (mm/s)	200.0
MaxPower (%)	50.0
MinPower (%)	40.0

Table 5-2-1 Idle Laser Power Instruction

Name	Instruction
Key Move Speed (mm/s)	The moving speed of laser head when pressing direction keys.
Max Power (%)	Laser power when pressing 【Laser】 .

6. System Menu

6.1 U Disk Files

Insert a U disk into the U disk slot on the panel. After the indicator lights, press **【Menu】** to enter the main menu, move the cursor to **【U Disk Files】**, press **【Enter】** to enter U disk files management interface.

Figure6-1-1 Main Menu Interface






Figure6-1-2 U Disk Files



- ① The U disk must be formatted to FAT32 File system in advance. Quick Format is forbidden. Any other files formations are not supported.
- ② Recommend using a U disk with a "light indicator" to ensure if the U disk is connected successfully with the main board
- ③ When the U disk has never been able to read, try using a different U disk.
- ④ The U disk can't be used to install system.

If the U disk can't be read, you will see the interface below.


Figure6-1-3 No U Disk Interface



6.1.1 Work Files

Move the cursor to **【Work Files】** and press **【Enter】**. On the panel, the working file in the U disk will be presented. The right side shows the working file previewing. Press **【↑】** **【↓】** to move cursor and press **【Enter】** to copy the working file from U disk to main board storage.

Figure6-1-4 U Disk Work Files List




The working file in the U disk is saved with a suffix of UD5. Files other than the ".UD5" file extension will not be readable.

6.1.2 Config Files

Move cursor to **【Config File】** and press **【Enter】**. Move cursor to the file which you need to copy to main board. Then Press **【Enter】** to save current config file to mainboard.


Figure6-1-5 Config Files List



6.1.3 Upgrade Files

Move cursor to **【Upgrade Files】** and press **【Enter】** . Move the cursor to the file you need, press **【Enter】** then it will start the upgrading process.

Figure6-1-6 Upgrade Files





Don't turn off the power during upgrade, otherwise it will cause damage to the mainboard. The upgrade will take about 30s. After finishing upgrade, the mainboard will reset automatically.


6.1.4 Save Current Config to U Disk

Move cursor to **【Save Current Config to U Disk】** and press **【Enter】** to save current mainboard config file to the U disk. And the file will be named as "Params.CF5" in the U disk.

6.2 Origin Manage

On the main page, press **【Menu】**, and move cursor to **【Origin Manage】**, press **【Enter】**. You will see ***Origin Manage*** page.


Figure6-2-1 Origin Manage Interface



Move cursor to **【Origin1 Manage】** , press **【Enter】** to enter the **Origin1 Manage** interface. Move cursor to **【Set current position as the origin】** , press **【Enter】** to set the current position of laser head as origin point. Other origin points will be set like this.

【The origin PX】 and **【The origin PY】** show the coordinates of current origin point. Users can accurately determine the origin point according to the coordinate value. The system supports up to 4 origin points. Users can select any origin points for use by pressing **【Move head to the origin】** key. This function is used for rapid switching of different points of laser head. Take **【Origin1 Manage】** as an example.

Figure6-2-2 Origin Mange Instruction




6.3 Jog Control

On the main page, press **【Menu】**, move cursor to **【Jog Control】** and press **【Enter】** to enter ***Jog Control*** page. Then press **【Z ↑】【Z ↓】** to modify the distance. Do not set too large **【Jog Distance】**, please make sure it within the working range.

On the ***Jog Control*** page, press **【Z ↑】【Z ↓】** to modify the jog distance, and press **【↑】【↓】** to move cursor to axis jog options, then press **【Z ↑】【Z ↓】** to move cursor, press **【↑】【↓】【←】【→】** to make X/Y/Z axis jog.

The jog control can move axis accurately and adjust the distance per pulse of axis. [Please check the Chapter 3.5 to know more about distance per pulse.](#)

Figure 6-3-1 Jog Control Interface



6.4 Cut Box

On the main page, press **【Menu】** and move cursor to **【Cut Box】**, press **【Enter】** to enter the **Cut Box** page. Move cursor to **【Blank Distance】**, and press **【Z ↑】****【Z ↓】** to modify parameters, then move cursor to **【Start cutting box】** and press **【Enter】** to start cut box function.

When cutting box, the laser head keeps a certain distance (Blank Distance) from the outside edge of the graphics from the registration point, and cuts a square, which is used to determine the location of the origin point of the laser head and the actual size of graphics.

Figure 6-4-1 Cut Box Interface




Table6-4-1 Cut Box Instruction


Name	Instruction
Blank Distance (mm)	The distance between the border of graphics s and the border of cutting.

6.5 Axes Control

On the main page, press **【Menu】** and move cursor to **【Axes Control】** , press **【Enter】** to enter ***Axes Control*** page. Press **【↑】****【↓】** to move cursor, and press **【Enter】** .

The Z axis can be used as the lifting shaft, platform lifting shaft. When the Z axis is reset, the Z axis will stop at the limiter position.

Fiugre6-5-1 Axes Control Interface



6.6 Motion Parameters Settings

On the main page, press **【Menu】** and move cursor to **【Motion Parameters Settings】**, press **【Enter】** to enter ***Motion Parameters Settings*** page. Press **【↑】【↓】** to move cursor and press **【Z↑】【Z↓】** to modify parameters, press **【Enter】** to save settings.




The settings of motion parameters interface are valid for X/Y axis and have no influence on Z/U axis.

Figure 6-6-1 Motion Parameters Settings Interface

Motion Parameters Settings		2019.1.18 10:35
➡	Space Speed (mm/s)	0300.0
	Cut Jerk (10000mm/s ³)	08.0
	Space Jerk (10000mm/s ³)	10
	Min Acc (mm/s ²)	0300
	Engrave Acc (mm/s ²)	10000
	Start Speed (mm/s)	10.0
	Speed Factor	3.0

The settings of these parameter items will affect the cutting effect, please adjust according to your requirements.

Table6-6-1 Motion Parameters Instruction

	Name	Instruction
	Space Speed (mm/s)	The movement speed of laser head when there is no laser output.
	Cut Jerk (mm/s3)	The variation of cutting acc increases or decreases in unit of 10 thousand each time.
	Space Jerk (mm/s3)	The variation of movement acc when there is no laser output and it increases or decreases in unit of 10 thousand each time.
	Min Acc (mm/s2)	The acceleration of laser head when it turns and this value increases or decreases in unit of 50 or 100 each time.
	Engrave Acc (mm/s2)	The variation of engraving speed and it is only effective to engrave.
	Start Speed (mm/s)	The initial speed of laser head from rest to motion.
	Speed Factor	Parameter changes throughout the system. We suggest that lower speed is going to be filled in with 0.5 or 1, while regular speed with 2 and high speed with 3 or 4. This option should be filled in with 0.05 when cutting acrylic or wood. It also has

		an impact on smoothness when turning.
--	--	---------------------------------------

During the cutting process, if the actual cutting speed is far less than the working speed users have set, it indicates that the **【Cut Jerk】** is set too small, so that the laser head cannot reach the set working speed quickly. If the actual cutting speed is relatively fast, the cutting line will jitter, this case indicates that the **【Cut Jerk】** is set too high and the parameter value should be reduced. In the same way, if the **【Space Jerk】** is set too small, the speed of laser head will not reach the set speed when there is no laser output. If the parameter is set too large, the initial position of cutting (after the laser head moving without laser) will jitter.

The start speed is the initial speed of the laser head from rest to start movement. If the cutting line is too thick at the initial position of cutting, it indicates that the parameter value is too small. If the line jitters at the initial position of cutting, this parameter value is set too large.

The speed factor controls the speed of turning during cutting. If the cutting line is too thick when turning, the parameter is too small. If the cutting line is too thin when turning and the graphics cannot be cut completely, this case indicates that this parameter value is set too large, users should set a smaller value.


The **【Engrave ACC】** is the change rate of speed during engraving. This parameter is only valid during engraving. During the engraving process, if the space distance of laser head is too large, then the **【Engrave ACC】** is

set too small and should be adjusted appropriately. If the space distance of laser head is too small and the edge of graphics is not carved completely, it indicates that the **【Engrave ACC】** is set too large and should be reduced appropriately.

6.7 Common Parameters Settings

On the main page, press **【Menu】** and move cursor to **【Common Parameters Settings】**, press **【Enter】**.

Figure 6-7 Common Parameters Settings Interface



6.7.1 Work Mode

On the **Common Params Settings** page, move cursor to **【Work Mode】** and press **【Enter】**. Press **【↑】****【↓】** to move cursor, press **【←】****【→】** to modify options and press **【Enter】** to save settings.

Figure6-7-1 Common Parameters Settings Interface

Work Mode		2019.1.18 10:35
➡	Go Origin After Reset	Enable
	Origin Mode	Soft Origin
	GoBack Position	Current Origin
	Count Mode	Count per work
	Auto Origin (Beyond border limit)	Disable

Table6-7-1 Work Mode Instruction

Name	Instruction
Go Origin After Reset	<p>Enable: the laser head will be back to Origin after resetting.</p> <p>Disable: the laser head will stay at the machine origin point (zero point) after reset.</p>
Origin Mode	<p>Current Position: keep the current position of laser head and set this position as origin point to start cutting.</p> <p>Key Origin: press panel 【Origin】 button after the laser head moved to the chosen position.</p> <p>Soft Origin: set the origin point when drawing a file on LaserCAD software.</p> <p>Machine Zero As Origin: set the machine zero point as origin</p>

	point.
Go Back Position	<p>Current Position: laser head will stay at where task finished.</p> <p>Current Origin: go back to Origin point after finishing work.</p> <p>Zero Coord: laser head goes back to machine zero point since all finished.</p>
Count Mode	<p>Count per work: it will be counted as once after all files cut.</p> <p>Count per Light: it will be counted as once after laser optical output one time.</p> <p>Single of Array: it will be counted as once after the solid graphics in the file is cut.</p>
Auto Origin (Beyond border limit)	Enable or disable the function.

Users can enable or disable the Auto Origin (Beyond border limit) function as required. Disable the function, if the graphics beyond the working range, the system prompts "Beyond border limit! Continue?", press **【Enter】** key to continue to cut, part of the graphics beyond border limit will not be cut, as shown in Figure 6-7-3,6-7-4. Press **【ESC】** to cancel operation.

Figure 6-7-2 Beyond Border Limit




Figure 6-7-3 Part of the Cutting (Panel)





Figure 6-7-4 Part of the Cutting (LaserCAD)




Enable the function, if the graphics beyond the working range, the laser head will automatically adjust position to cut the graphics perfectly. After adjustment, if the graphics still beyond the border, the system prompts "Beyond border limit! Continue?", press **【Enter】** key to continue to cut, part of the graphics beyond border limit will not be cut, as shown in Figure 6-7-3/6-7-4. Press **【ESC】** to cancel operation.

As shown in Figure 6-7-5, the green graphics is beyond the current working range. If enable the function **【Auto Origin (Beyond border limit)】**, the machine will automatically move to the position of the red graphics for cutting. If the graphics is still beyond the border after re-positioning or

disable the function, the machine will only cut part of the graphics which is within the working range like Figure 6-7-4.

Figure 6-7-5 Auto Origin



6.7.2 Common Parameters

On the **Common Params Settings** page, move cursor to **Common Parameters** and press **Enter**. Press **↑** **↓** to move cursor and press **Z ↑** **Z ↓** to modify parameters, press **Enter** to save settings. The **Z AutoFocus** function is mainly used to control the distance between the laser head and the work table. If the Z axis is used as the lifting shaft

or platform lifting shaft, users can turn on the **【Z AutoFocus】** function on the **Function Config** page (**【Manufacturer Params Settings】** → **【Function Config】**) and set **【AutoFocus Distance】** here to keep the distance between laser head and working table.

Figure6-7-6 Common Parameters Interface

Common Parameters		2019.1.18 10:35
➡	AutoFocus Distance (mm)	00.0
	KeyMove' Speed (mm/s)	200.0
	RunBox' Speed (mm/s)	200.0
	CutBox' Speed (mm/s)	050.0
	Blow Open Delay (s)	0.00
	Blow Close Delay (s)	0.00

Table6-7-2 Common Parameters Instruction

Name	Instruction
Auto Focus Distance (mm)	The distance between the laser head and working platform.
Key Move Speed (mm/s)	The motion speed of axis when press the direction keys on panel.
Run Box Speed	The speed at which the laser head runs along the outer

(mm/s)	frame of graphics without laser output.
Cut Box Speed (mm/s)	The speed at which the laser head cuts along the outer frame of graphics.
Blow Open Delay(s)	The period between laser head optical output and air blowing started.
Blow Close Delay(s)	The period between laser head optical output stopped and air blowing stopped.

6.7.3 Axis Speed Parameters

On the **Common Params Settings** page, move cursor to **Axis Speed Parameters** and press **Enter**. Press **↑** **↓** to move cursor and press **Z ↑** **Z ↓** to modify parameters, press **Enter** to save settings.

Figure 6-7-7 Axis Speed Parameters Interface

Axis Speed parameters		2019.1.18 10:35
➡	Z Work Speed (mm/s)	080.0
	XY Home Speed (mm/s)	050.0
	Z Home Speed (mm/s)	040.0

Table6-7-3 Axis Speed Parameters Instruction

Name	Instruction
Z Work Speed (mm/s)	The work speed of Z axis.
XY Home Speed (mm/s)	The reset speed of XY axis.
Z Home Speed (mm/s)	The reset speed of Z axis.

6.7.4 Rotate Engraving & Cutting

On the **Common Params Settings** page, move cursor to **Rotate Engraving & Cutting** and press **Enter** . Press **↑** **↓** to move cursor, press **←** **→** to modify options and press **Z ↑** **Z ↓** to modify parameters, press **Enter** to save settings.

Figure 6-7-8 Rotate Engraving & Cutting Interface

Rotate Engraving&Cutting		2019.1.18 10:35
➡ Rotary	Disable	
Rotary Axis	X	
Pulse Count Per Rotate	010000	
Current Diameter(mm)	100.0	


Table 6-7-4 Rotate Engraving & Cutting Instruction

Name	Instruction
Rotary	Enable or Disable rotary engraving function.
Rotary Axis	The axis which rotary engraving uses.
Pulse Count Per Rotate	The pulse parameters for the motor to make the rotary axis rotate one circle.

Current Diameter (mm)	The diameter of the material being processed.
--------------------------	---

After enable the **【Rotary】** function, reset the machine, the panel prompts “Rotary is Enabled!”. If the current machine does not support the rotate engraving function, the distance per pulse of rotary axis will change, and the machine cannot cut the graphics normally. After turning off the function, reset the machine again, users do not need to set axis parameters (like distance per pulse) the machine can work normally.


Figure 6-7-9 Enable Rotate Engraving & Cutting Function



Rotate engraving includes fixture type and roller type, as shown in figure 6-7-10/6-7-11. The fixture rotate engraving cutting only needs to input the pulse count per rotate and current diameter. The calculation formula of pulse count per rotate is as follows:

Pulse Count per Rotate = Pulse Number of Motor * (Number of Gears in Gear1 / Number of Gears in Gear2)

Figure6-7-10 Fixture Rotate Engraving



Users should adjust distance per pulse of rotary axis for roller type rotate engraving & cutting (Pulse count per rotate is noneffective). Take X axis as rotary axis as example.

1. Wrap a layer of paper around the roller.
2. In the computer software LaserCAD, draw A straight line section with fixed length as "A" (less than the current cutting object girth).
3. Press 【Start/Pause】 key to cut the line on the paper.
4. Take the same length of the cut trace along the roller with one wool or other convenient object, and measure the length of this wool segment as "B" accurately with a ruler.

5. Enter the ***X Axis Parameters*** interface, move the cursor to **【Distance per Pulse】**, press **【Enter】** key to enter the ***To Calculate the Pulse Distance*** interface, fill A into the **【Expected Length】** option, fill B into the **【Actual Length】** option, and click **【Enter】** key to calculate the distance per pulse of X axis (rotary axis).

Figure6-7-11 Roller Rotate Engraving & Cutting



6.8 Network Settings

On the main page, press **【Menu】**, move cursor to **【Network Settings】** and press **【Enter】**. Press **【↑】****【↓】** to move cursor, press **【Z↑】****【Z↓】** to modify parameters and press **【Enter】** to save settings.

Figure6-8-1 Network Settings


Network Setting		2019.1.18 10:35
➡ IP Part1		192
IP Part2		168
IP Part3		008
IP Part4		008

The default IP address of the panel is 192.168.8.8. When connecting the main board and PC terminal through network cable, the computer IP should be modified to make the computer IP address and IP address of the main board in the same network segment. For example, the computer IP address can be set to 192.168.8.28.

Based on the Windows7 system, users can modify the native IP address in the following ways. First, open the Control Panel, select Network and Internet options, and click View Network Status and Tasks. Then, double-click the Local Connection, click the Property button, and double-click the

TCP/IPv4 option to open the IP address modification interface. Finally, input the corresponding IP address, click OK button to save, other parameters do not need to fill in.


Figure6-8-2 Modify IP Address



6.9 Language

On the main page, press **【Menu】** and move cursor to **【Language】**, press **【Enter】**. Press **【←】** **【→】** to change language and press **【Enter】** to save settings. AWC708S now supports nine kinds of languages, Simplified Chinese, Traditional Chinese, English, Portuguese, Turkish, Russian, French, Korea and Arabic.

Figure 6-9-1 Language Interface



6.10 System Version

On the main page, press **【Menu】** and move cursor to **【System Version】**, press **【Enter】** to see the system information.

If the encryption or decryption of the mainboard is successful, the product ID will change.

Figure 6-10-1 System Version Interface

System Version		2019.1.18 10:35
Product Name	AWC708S	
Product ID	0201E014 00000000	
Version	1.19.1.6	
➡ User authorization code		

Move cursor to【User authorization code】and press 【Enter】. Press【 ↑ 】
【 ↓ 】 to move cursor, press 【Z ↑ 】【Z ↓ 】 to modify parameters and press
【Enter】 to save settings.

The user authorization code is used for encryption or decryption. If you don't need encryption, there is no need to modify it. If you need encryption, please see the detail in encryption manual.


Figure 6-10-2 User Authorization Code Interface

User authorization code		2019.1.18 10:35
➡	Code 1	100000
	Code 2	100000
	Code 3	100000

7. Manufacture Params Settings

On the main page, press **【 Stop 】** + **【 Shift 】** together, you will see ***Manufacture Params Settings*** page.


Figure7-1 Manufacture Params Interface



7.1 Axis Parameters


Move cursor to **【 Axis Parameters 】** and press **【 Enter 】** . Take the X axis parameter setting as an example, other axis parameter settings are the same.

Figure7-1-1 Axis Parameters Interface



On the **X Axis Parameters** page, press **【↑】****【↓】** to move cursor, press **【←】****【→】** to modify options, press **【Z↑】****【Z↓】** to modify parameters and press **【Enter】** to save settings.

Figure7-1-2 X Axis Parameters Interface



Move cursor to **【Distance Per Pulse】** , press **【Enter】** to enter the **To**

Calculate the Pulse Distance page. Press **【 ↑ 】****【 ↓ 】** to move cursor, press **【 Z ↑ 】****【 Z ↓ 】** to modify parameters, and press **【 Enter 】** to calculate the distance per pulse. [The calculation of distance per pulse, please refer to the Chapter 3.5 for more details.](#)

Figure7-1-3 Calculate the Distance Per Pulse

To Calculate the pulse Distance		2019.1.18 10:35
➡	Expected Length (mm)	0200.00
	Actual Length (mm)	0200.00

Table7-1- X Axis Parameters Instruction

Name	Instruction
Distance Per Pulse (um)	The single distance or angle which the motor moves, when the controller sends a pulse signal. If set incorrectly, the graphics will change.
Valid Pulse Edge	Effective values for driver level to change, Falling Edge or Rising Edge.
Datum Direction	The direction in which the machine moves when reset. If set incorrectly, the axis moves against origin direction.

Key Direction	The direction in which the axis moves when press keys on the panel. When set incorrectly, the axis moves opposite direction.
Limit Polarity	The control level that limit switch passes to the control panel. When set incorrectly, the limit will fail. If the limit sensor is NPN, the limit polarity is negative. If the limit sensor is PNP, the limit polarity is positive.
Range(mm)	The working range of machine.
Start Speed (mm/s)	The initial speed at which the axis moves from rest to motion.
Max ACC (mm/s ²)	The maximum acceleration value of the motion axis when the axis increases or decreases speed.
Max Speed (mm/s)	The maximum speed which the motion axis supports.
Zero Offset (mm)	The zero point of machine will move a zero offset distance along X+ direction.

In some special cases, the machine's origin point cannot be cut. AWC708S supports the Zero Offset function, which can move the zero point of machine to other positions along the positive direction of the motion axis. Take X axis as example, if the X axis **【Zero Offset】** is set to 50mm, the machine origin point will move 50mm along X+ direction, and this position is the new origin (zero) point of machine.

7.2 Laser Parameters

On the **Manufacture Params Settings** page, move cursor to **【Laser Parameters】** and press **【Enter】**. Press **【↑】【↓】** to move cursor, press **【←】【→】** to modify options, press **【Z↑】【Z↓】** to modify parameters and press **【Enter】** to save settings.

Figure7-2-1 Laser Parameters Interface

Laser Parameters		2019.1.18 10:35
➡ Laser Mode	CO2 Glass Tube	
TTL Valid Level	Low Level	
PWM Frequency (hz)	20000	
Max Power (%)	98	
RF Min Power (%)	0.0	
Water Protect	Disable	

Table7-2-1 Laser Parameters Instruction

Name	Instruction
Laser Mode	Laser tube type: CO2 Glass Tube, RF tube.
TTL Valid Level	The control level of laser tube.
PWM Frequency (Hz)	Set the pulse frequency of control signal used by laser.

Max Power (%)	The maximum power of laser tube. The maximum power value set by user can't be higher than this value and the laser power is displayed as a percentage.
RF Min Power (%)	Turning power.
Laser Water Protect	Water protection switch. If enable this function, the machine will stop working when the machine detects the signal of water stopping.

7.3 I/O Parameters

On the **Manufacture Params Settings** page, move cursor to **IO Parameters** and press **Enter**. Press **↑** **↓** to move cursor, press **←** **→** to modify options and press **Enter** to save settings.

If want to use feed function, users should enable **Feed Switch** on this page.

Figure7-3-1 I/O Parameters Interface

IO Parameters		2019.1.18 10:35
→ Foot Switch	Disable	
Open Protection	Disable	
Input Valid Level	Low Level	

Table7-3-1 I/O Parameters Instruction

Name	Instruction
Foot Switch	Enable or disable the foot switch function.
Open Protection	Enable or disable the open protection function.
Input Valid Level	Set input IO to low level or high level.

7.4 Auto Reset Settings

On the **Manufacture Params Settings** page, move cursor to **Auto Reset Settings** and press **Enter**. Press **↑** **↓** to move cursor, press **←**

→ to modify options and press **Enter** to save settings.

In general, we suggest users to enable axis AutoReset function, and disable the feed axis AutoReset.

Figure7-4-1 Auto Reset Setting Interface




Table7-4-1 Auto Reset Settings Instruction

Name	Instruction
XY Auto Reset	If enable this function, when power on or reset the machine, the XY axis will reset to origin point.
Z Auto Reset	If enable this function, when power on or reset the machine, the Z axis will reset to origin point.

7.5 HardLimit Settings

On the **Manufacture Params Settings** page, move cursor to **HardLimit Settings** and press **Enter**. Press **↑** **↓** to move cursor, press **←**

→ to modify options and press **Enter** to save settings.

AWC708S supports working range limit, users do not need to install hard limiter in general, just set the **Range** on the axis parameters page.

Figure7-5-1 HardLimit Setting Interface




Table7-5-1 Auto Reset Settings Instruction

Name	Instruction
X HardLimit	HardLimit switch of X axis. If use HardLimit, enable the function here.
Y HardLimit	HardLimit switch of Y axis. If use HardLimit, enable the function here.
Z HardLimit	HardLimit switch of Z axis. If use HardLimit, enable the function here.

7.6 Function Config

On the **Manufacture Params Settings** page, move cursor to **Function Config** and press **Enter**. Press **←** **→** to modify options and press **Enter** to save settings.

Figure7-7-1 Function Config Interface




Table7-7-1 Function Config Instruction

Name	Instruction
Z-Axis for Autofocus	The switch of Z-axis Autofocus. If you need Z AutoFocus function, you need to enable this option. This parameter is mainly to control the distance between laser head and working platform.

8. FAQ

1. The top bar displays local date and time. The date and time can be modified, which requires the cooperation of encryption software. If the time changes to 0.0.0, it means the battery in the panel has run out of power and can't set password for control card. The clock doesn't support power off relay function.
2. When the file name is in Chinese, it can only show 4 Chinese characters at most, and they are in common Chinese character library. A file name can display up to 8 characters when it uses number or English characters.

Appendix 1: Wiring Diagram of Servo Driver

1. Panasonic A5 High Speed Pulse Wiring Diagram

Figure 1-1 Panasonic A5 High Speed Pulse Wiring Diagram




Figure 1-2 Panasonic A5 Low Speed Pulse Wiring Diagram




Table1-1 Panasonic A5 Series Basic Setting Parameters

Mode	Value	Instruction
Pr001	0	Control mode, must be set to position mode.
Pr007	3	Must be "Pulse + Direction" mode.
Pr005	1	<p>High-speed pulse connection mode, the parameter is set to "1", and the maximum pulse frequency is 3Mpps.</p> <p>Low speed pulse connection mode, the parameter is set to "0", and the maximum pulse frequency is 500Kpps.</p>

2. Yaskawa Wiring Diagram

Figure 2-1 Yaskawa Wiring Diagram




Table2-1 Yaskawa Σ Series Basic Setting Parameters

Mode	Value	Instruction
Pn000	001X	Position mode.
Pn00B	None	When single-phase power input, the parameter is set to "0100".
Pn200	2000H	<p>Positive logic: Pulse + Direction;</p> <p>0005H negative logic: Pulse + Direction;</p> <p>When the pulse frequency is less than 1Mpps, please select "0000H".</p> <p>When the pulse frequency reaches 1Mpps~4Mpps,</p>

		please select "2000H".
Pn50A	8100	Positive rolling side can be driven.
Pn50B	6548	Negative rolling side can be driven.

3. Delta A Series High Speed Pulse Wiring Diagram

Figure 3-1 Delta A Series High Speed Pulse Wiring Diagram




Figure 3-2 Delta A Series Low Speed Pulse Wiring Diagram




Table3-1 Delta ASD-A Series Basic Setting Parameters

Mode	Value	Instruction
P1-00	1102H	<p>Position control mode, negative logic: "Pulse + Direction".</p> <p>Set the parameter to "1102H" to open the high-speed differential signal, and the maximum pulse frequency is 4Mpps;</p> <p>Set the parameter to "0102H" low-speed pulse signal, and the maximum pulse frequency is 500K.</p>
P1-01	00	Select the location mode controlled by the external instruction.
P2-10	101	DI1 is set to SON servo enablement, and the logic is

		normally open.
P2-14	102	DI5 is set as ARST clear alarm function, the logic is normally open.
P2-12	007	DO5 is set as ALRM servo alarm function, the logic is normally closed.

4. Sanyo R Series Wiring Diagram

Figure 4-1 Sanyo R Series Wiring Diagram




Table4-1 Sanyo R Series Basic Settings Parameters

Mode	Value	Instruction
SY08	00	Position mode.
Gr8.11	02	Pulse signal mode: Pulse + Direction.
Gr9.00	00	Positive rolling side can be driven.
Gr9.01	00	Negative rolling side can be driven.

5. Schneider 23A High Speed Pulse Wiring Diagram

Figure 5-1 Schneider 23A High Speed Pulse Wiring Diagram




Figure 5-2 Schneider 23A Low Speed Pulse Wiring Diagram




Table5-1 Schneider Lexium 23D Series Basic Settings Parameters

Mode	Value	Instruction
P1-00	1102H	<p>Position control mode, negative logic: "Pulse + Direction".</p> <p>Set the parameter to "1102H" to open the high-speed differential signal, and the maximum pulse frequency is 4Mpps;</p> <p>Set the parameter to "0102H" low-speed pulse signal, and the maximum pulse frequency is 500K.</p>
P1-01	X00	Select the location mode controlled by the external instruction.
P2-10	101	Change the servo IN1 to SON function.

P2-11	0	We do not use IN2。
P2-13~P2-17	0	We do not use IN4~IN8。

6. Fuji A5 Series Wiring Diagram

Figure 6-1 Fuji A5 Series Wiring Diagram

AWC708S Servo Control Interface

Signal	PIN
DIR	1
PUL	2
DC 5V	3

Fuji A5-26P Interface

PIN	Signal
7	CA
8	*CA
20	CB
21	*CB




Table6-1 Fuji ALPHA 5 Series Basic Setting Parameters

Mode	Value	Instruction
PA-101	0	Position control mode.
PA-103	0	Pulse + Direction, the maximum pulse frequency is 1Mpps.

7. Mitsu Series Wiring Diagram

Figure 7-1 Mitsu J3 Series Wiring Diagram




Figure 7-2 Mitsu E Series Wiring Diagram




Table7-1 Mitsu MR-J3—A Series Basic Setting Parameters

Mode	Value	Instruction
PA01	0	Control mode: Position mode.
PA13	0011	Negative logic: Pulse + Direction.

Notice: The maximum pulse frequency of Mitsu J3 Series is 1Mpps.